

ST 30 Series Wall & Duct Mount Versatile Temperature Transmitter



Installation Manual

PPI



101, Diamond Industrial Estate, Navghar,
Vasai Road (E), Dist. Palghar - 401 210.
Sales : 8208199048 / 8208141446
Support : 07498799226 / 08767395333
E: sales@ppiindia.net, support@ppiindia.net

May 2025

► Dimensions (mm)




► Wiring Instructions




► Installation & Mounting Holes

1. Drill holes
2. Insert plastic expansion pipe
3. Flush mount the Transmitter
4. Fix screws



Duct Mount



1. Drill holes
2. Mount oval flange
3. Fix screws to secure flange
4. Insert the transmitter probe through the flange hole and adjust the insertion length
5. Fix the clamp screw to secure the probe