



control solutions

TERACOM



TCW210-TH Temperature and humidity data logger

Revision 1.21 / October 2023

USER MANUAL

www.teracomsystems.com

1. Introduction

TCW210-TH is a temperature and humidity data logger with an embedded WEB server. Real-time data and charts of temperature, humidity and dew point can be monitored with a standard web browser (no special software is needed). Standard protocols as SNMP, MODBUS/TCP, and HTTP/API are available for M2M applications. The device supports also interface to popular IoT analytics – ThingSpeak.

The Ethernet temperature logger supports up to eight temperature or humidity-temperature sensors. All they can be connected either to the 1-Wire interface, popular for home automation or to more robust MODBUS RTU over RS-485.

All monitored parameters can be recorded, in internal FLASH memory. The records are made on the previous set time interval and/or on an alarm condition. The memory is large enough for at least 36 days with records on every minute. The log file can be periodically uploaded on a dedicated server by HTTP/HTTPS Post. The stored data can be monitored on 4 graph pages.

XML/JSON file with all monitored parameters can periodically upload to a dedicated server by HTTP/HTTPS Post.

For every monitored parameter e-mails and SNMP traps for up to 5 recipients can be sent. Alarm alert can also be sent by HTTP/HTTPS Post with XML/JSON status files.

2. Features

- Data logger for up to 70000 records;
- 1-Wire and MODBUS RTU sensors support;
- HTTP API commands;
- Periodical HTTP/HTTPS Post of XML/JSON status files for client-server systems;
- SNMP v.2 support;
- SNMP traps to up to 5 recipients like alarm alert;
- MODBUS TCP/IP support;
- SMTP with TLS encryption;
- TLS 1.0, TLS 1.1 and TLS 1.2 support;
- e-mails to up to 5 recipients like alarm alert;
- ThingSpeak service support;
- NTP support;
- Back-up/Restore of configurations;
- Dynamic DNS support;
- 10/100 Mb Ethernet connectivity;
- Auto-MDIX;
- Port changing for HTTP, SNMP and MODBUS TCP/IP;
- Password protected WEB based configuration and control;
- Extended working temperature range;
- Wide power supply voltage range;
- Remote firmware update.

3. Applications

TCW210-TH is suitable for environmental monitoring, building, and industrial automation.

It works very well for monitoring temperature and humidity as a standalone device using a WEB browser only or as a part of small to large industrial control systems for SCADA (supervisory control and data acquisition).

A few application examples - pharmaceutical and food processing and storage, clean rooms, laboratories, HVAC systems, greenhouses and farms, electronic assembly etc.

4. Specifications

- Physical characteristics
Dimensions: 130 x 70 x 30 mm
Weight: 140 g
- Environmental limits
Operating temperature range: -20 to 55°C
Storage temperature range: -25 to 60°C
Operating relative humidity range: 5 to 85% (non-condensing)
- Warranty
Warranty period: 3 years
- Power requirements
Input Voltage: 10 to 28 VDC
Input Current: 170 mA @ 12 VDC
- 1-Wire and RS485 interface
Output voltage (+VW): 5.0 ± 0.3 VDC
Maximum output current (+VW): 0.2 A
- Internal FLASH memory
Endurance: 100 000 cycles (Every settings change is a memory cycle.)

5. LED indicators

The following indicators show the status of the controller:

- **PWR** (red) – in working mode shines, flashes together with STS if there is a hardware error;
- **STS** (yellow) – flashes when the main program of the controller is executed;
- **NET** (orange) – indicates the network connection status - ON when a link is established, flashing when there is an activity.

6. Installation and setup

This device must be installed by qualified personnel.

This device must not be installed directly outdoors.

The installation consists of mounting the device, connecting to an IP network, connecting inputs and outputs, providing power and configuring via a web browser.

6.1. Mounting

TCW210-TH should be mounted in a clean and dry location on a not flammable surface. Ventilation is recommended for installations where the ambient air temperature is expected to be high.

Maintain spacing between adjacent equipment. Allow 50 mm of space on all sides, as shown in Appendix A, this provides ventilation and electrical isolation.

6.2. Connection

Attention! Disconnect power supply before wiring.

The correct wiring procedure is as follows:

- Make sure power is turned off;
- Apply all sensors;
- Apply power.

Make sure that cables are properly attached. Not proper wiring and configuration can cause permanent damage to TCW210-TH or the equipment to which it is connected or both.



| | | | |
|--------------------|--|--------------------|---|
| Connector 1 | Ethernet - RJ45 | Connector 4 | Pin1 – not connected (most left) Pin2 – not connected |
| Connector 2 | Power - 2.1x5.5mm connector, central positive | | Pin3 – not connected Pin4 – Line B- Pin5 – Line A+ Pin6 – not connected Pin7 – +VDD Pin8 – GND |
| Connector 3 | Pin1 – GND (most left) Pin2 – GND Pin3 – 1-Wire Data Pin4 – 1-Wire GND Pin5 – +VDD Pin6 – +VDD (most right) | | |

6.2.1. Power supply

TCW210-TH is designed to be supplied by adapter SYS1421-0612-W2E or similar, intended for use in the conditions of overvoltage category II, and prior assessed for compliance with safety

requirements. The power supply equipment shall be resistant to short circuit and overload in a secondary circuit.

When in use, do not position the equipment so that it is difficult to disconnect the device from the power supply.


6.2.2. 1-Wire interface

1-Wire is a registered trademark of Maxim Integrated Products, Inc. It is designed to connect several sensors over short wiring. It is not suitable for long distances or environments with EMC interference.

The maximum number of sensors (1-Wire or RS-485) connected to TCW210-TH is 8.

The device supports temperature and humidity-temperature sensors. Connected sensors are automatically detected and the appropriate dimension is assigned.

It is strongly recommended to use “daisy-chained” (linear topology) for multi-sensors systems:



It is strongly recommended to use only UTP/FTP cables and keep total cable length up to 30m. Although functionality has been achieved in the longer distance, we cannot guarantee error-free operation over mentioned wiring length. We recommend reading Maxim’s 1-Wire tips at <https://www.teracomsystems.com/wp-content/uploads/1-wire/guidelines-for-reliable-long-line-1-wire-networks.pdf>.

We guarantee proper operation only with Teracom 1-Wire sensors.

6.2.3. RS-485 interface


RS-485 is a standard for serial communications systems defined by Telecommunications Industry Association (TIA) and Electronic Industries Alliance (EIA). Implementing the standard, communication systems can be used effectively over long distances and in electrically noisy (industrial) environments.

The maximum number of sensors (1-Wire or RS-485) connected to TCW210-TH is 8.

The device supports temperature and humidity-temperature sensors.

MODBUS RTU protocol specifies that address of the device should be between 1 and 247. The user should take care of appropriate address settings.

For multi-sensors systems “daisy-chained” (linear topology) should be used:



Interconnections are realized by UTP/FTP cables with RJ-45 connectors. The popular Ethernet wiring standard ANSI/TIA/EIA T568B is used:

| Pin# | RJ45 |
|------|--------------|
| 1 | Orange/White |
| 2 | Orange |
| 3 | Green/White |
| 4 | Blue |
| 5 | Blue/White |
| 6 | Green |
| 7 | Brown/White |
| 8 | Brown |

It is recommended to use standard patch cables for LAN networks.


Special attention should be paid on termination of the bus in the last sensor.

We recommend keeping total cable length up to 30 m, although the RS-485 interface works over a much longer distance.

Attention! Special care should be paid on termination of the bus. The last sensor in the chain should have a 120-ohm terminator installed on the free RJ-45 socket. The terminator is delivered with the module.

6.2.4. Network connection


The Ethernet port of TCW210-TH should be connected to 10/100 Base-T Ethernet hub, switch or router.



For setup, TCW210-TH may be connected directly to the Ethernet port on a computer. The device support Auto-MDIX and it is not necessary to use “crossover” cable, standard “straight-through” can be also used.



TCW210-TH can be used in a wireless network by connecting through a wireless router.




6.3. Communication setup


By default TCW210-TH is delivered with the following network settings:

IP address: 192.168.1.2, Subnet Mask: 255.255.255.0, Default Gateway: 192.168.1.1


Communication with TCW210-TH can be established by assigning a temporary IP address to the computer. For computers with Windows OS assigning of IP address is made in “Local area connection properties”:




The address should be on the same network - for example 192.168.1.3:



To get access to the web interface, you should type `http://192.168.1.2` into the browser:



If the network settings are correct, the login pop-up window will appear:



All TCW controllers connected to LAN can be easily found by the free tool “TCW discoverer”.

It is available for Win and Mac operating systems and can be downloaded from www.teracomsystems.com.


7. Web interface

The WEB interface allows configuration, monitoring, and control. All pages are UTF-8 encoded. For the WEB interface, the device supports HTTP only (HTTPS is not supported).

If the controller is properly addressing, login pop-up window appears.

Authorization data must be entered (by default username=admin, password=admin).

It is recommended to change the username and password to prevent unauthorized access to the controller.



The controller supports a few active session.

7.1. Monitoring

Monitoring page displays the current state of TCW210-TH. It has one data and four graphs tabs.

7.1.1. Data

| 1-Wire sensors | | | | | |
|----------------|-------------|-------------|----------|-----------|--------------------|
| Pos | Description | Temperature | Humidity | Dew point | ID |
| 1 | S1:TST1xx | 22.438 °C | ----- | ----- | [2867895F07000058] |
| 2 | S2 | ----- | ----- | ----- | [0000000000000000] |
| 3 | S3 | ----- | ----- | ----- | [0000000000000000] |
| 4 | S4 | ----- | ----- | ----- | [0000000000000000] |

| Modbus sensors | | | | | |
|----------------|-------------|-------------|-----------|-----------|---------|
| Pos | Description | Temperature | Humidity | Dew point | Address |
| 5 | S5 | 22.439 °C | 31.444%RH | 4.694 °C | 1 |
| 6 | S6 | ----- | ----- | ----- | 0 |
| 7 | S7 | ----- | ----- | ----- | 0 |
| 8 | S8 | ----- | ----- | ----- | 0 |

The current state of TCW210-TH can be monitored on this page. There are two sections on the page - one for 1-Wire sensors and one for MODBUS RTU sensors.

TCW210-TH supports up to eight sensors. They can be connected to both interfaces in a random ratio, settable in section "Sensors ratio setup" on Setup->Sensors page. By default, the number of MODBUS RTU sensors are 4.

All detected 1-Wire sensors are shown in "1-Wire sensors" section. The sensors should be setup in section "1-Wire sensors setup" on Setup->Sensors page.

TeraCom 1-Wire temperature sensors readings are shown in the column "Temperature", while for dual sensors (TSH2xx) both column "Temperature" and "Humidity" are used. For dual sensors, the parameter Dew point is calculated.

All MODBUS RTU sensors are shown in "Modbus sensors" section. The sensors should be added and set up on Setup->Sensors page.


For every sensor, there are a description, value, and ID information. The description length is up to 15 characters. Default descriptions can be changed in Setup->Conditions page.

Dual sensors (humidity-temperature) have the two parameters. For these sensors, Dew point parameter is calculated automatically.

The page can be automatically refreshed on an interval of 0 to 253 seconds. Zero means no automatic refresh. This parameter is set in section Setup->System->Monitoring page automatic refresh. By default, it is 1 second.

7.1.2. Graphs

Every graph page can display up to 4 parameters with up to 2 different dimension.



For every parameter different color can be set. There are a few checkboxes for display modification.

Export of monitored parameters can be made from the page.

| | | |
|---|---|---|
| <p>Graph Name Graph-1</p> <p>S1:TST1xx Temperature ■</p> <p>S2:TST1xx Temperature ■</p> <p>S3:TSH2xx Temperature ■</p> <p>none ■</p> <p>Save</p> | <p>Period Last 12 hours</p> <p><input type="checkbox"/> Highlight alarm values</p> <p><input type="checkbox"/> Highlight series</p> <p><input type="checkbox"/> Highlight weekends</p> <p><input checked="" type="checkbox"/> S1:TST1xx Temperature</p> <p><input checked="" type="checkbox"/> S2:TST1xx Temperature</p> <p><input checked="" type="checkbox"/> S3:TSH2xx Temperature</p> <p><input checked="" type="checkbox"/> none</p> | <p>From <input type="text"/></p> <p>To <input type="text"/></p> <p>Export</p> |
|---|---|---|

7.2. Setup

7.2.1. Network

The network parameters are set on this page.

| Network setup | |
|-----------------|-------------------|
| Hostname | TCW210TH |
| Static/DHCP | Static |
| IP address | 192.168.32.121 |
| Subnet mask | 255.255.255.0 |
| Default gateway | 192.168.32.1 |
| DNS | 8.8.8.8 |
| MAC address | 5C:32:C5:00:69:01 |

The controller supports static and dynamic IP addresses.

It is good practice to change the default IP address of the controller immediately after first power-on. This will avoid collisions if many devices are used on the same network.

It may be necessary to clear the arp cache, each time you connect a new device to the network. This is done by typing `arp -d` in the command prompt window of the computer.

The "Hostname" is up to 15 characters. It is shown in the search results of TCW discoverer.

7.2.2. Sensors

7.2.2.1. Sensors ratio setup

Sensors ratio setup

Number of 1Wire sensors

Number of Modbus sensors

The ratio between 1-Wire and MODBUS RTU sensors can be set here. By default, it is 4:4.

7.2.2.2. 1-Wire sensors setup

1-Wire sensors setup

| Pos | Description | Temperature | Humidity | ID | Lock |
|-----|-------------|-------------|----------|--------------------|--------------------------|
| 1 | S1:TST1xx | 22.438° C | ----- | [2867895F07000058] | <input type="checkbox"/> |
| 2 | S2 | ----- | ----- | [0000000000000000] | <input type="checkbox"/> |
| 3 | S3 | ----- | ----- | [0000000000000000] | <input type="checkbox"/> |
| 4 | S4 | ----- | ----- | [0000000000000000] | <input type="checkbox"/> |

Detection is made either after power on or by the button “Scan for new sensors”. All found sensors are shown in ascending order refer their unique ID number.

It is possible to lock a 1-Wire sensor in a specific position. To do this all sensors should be added one by one. After every addition, a new scan should be made and a newly found sensor should be locked in its position. If all sensors are locked, removing one “in the middle” will not change the positions of other sensors after reset. This option is very useful when TCW210-TH is used as a part of a monitoring and control system managed either by SNMP or HTTP API commands.

7.2.2.3. MODBUS RTU communication setup

Modbus RTU communication setup

Bit rate Scan time-out for a sensor, ms Max scan time: 25935

Parity First address

Stop bits Last address

Found: 1 sensors with following addresses: 1

TCW210-TH supports MODBUS RTU over RS-485 interface. All sensors connected to this interface should work with the same communication settings.

By default, TCW210-TH works with the standard for MODBUS RTU settings – 19200, E, 1.

In the right part of the section, there is a tool for scan the MODBUS RTU interface. To optimize scan time, the appropriate address segment should be set up after this, the button “Save” on the bottom of the page should be pressed.

7.2.2.4. MODBUS RTU sensors

Modbus RTU sensors

| Pos | Sensor address | Data type | Data order | Temperature register | | Humidity register | | Response time-out, ms (10-500) ms |
|-----|--------------------------------|------------------------------------|--|----------------------------------|-----------|----------------------------------|-----------|--------------------------------------|
| | | | | Address | Raw value | Address | Raw value | |
| 5 | <input type="text" value="1"/> | <input type="text" value="float"/> | <input type="text" value="MSW first"/> | <input type="text" value="100"/> | 22.693 | <input type="text" value="102"/> | 31.341 | <input type="text" value="100"/> |
| 6 | <input type="text" value="0"/> | <input type="text" value="float"/> | <input type="text" value="MSW first"/> | <input type="text" value="100"/> | --- | <input type="text" value=""/> | --- | <input type="text" value="100"/> |
| 7 | <input type="text" value="0"/> | <input type="text" value="float"/> | <input type="text" value="MSW first"/> | <input type="text" value="100"/> | --- | <input type="text" value=""/> | --- | <input type="text" value="100"/> |
| 8 | <input type="text" value="0"/> | <input type="text" value="float"/> | <input type="text" value="MSW first"/> | <input type="text" value="100"/> | --- | <input type="text" value=""/> | --- | <input type="text" value="100"/> |

[Modbus sensors setup tool](#)

Max response time-out:

Polling time:

TCW210-TH supports Teracom and third-party MODBUS RTU sensors.

Before to add MODBUS RTU sensors, the user should take care of their address setting. It is not allowed to use two sensors with the same address. It is recommended to scan for new sensors before to make any changes.

For every sensor, an appropriate register address together with the data type and data order should be set. All changes should be saved. If the settings are OK in the columns “Raw value” the right data will be shown.

TCW210-TH supports MODBUS RTU sensors with response time-out between 10 and 500mS. The response time-out for a new sensor is 100mS by default but it is recommended to use minimum response time guaranteed by the sensor’s manufacturer.

The sum of chosen response time-out for every sensor forms the maximum response time-out for the system.

The polling time is the time between two sequential readings of the same sensor. The chosen polling time determines the system's time of reaction. By default, it is 1 second.

Important: The maximum response time-out can’t be lower than the polling time.

7.2.2.5. Sensor setup tool

The link for the tool is available on the bottom of the Modbus RTU sensors paragraph. It can be used for sensor communication setup changes or just to read information from a register.

7.2.2.5.1. Communication setup

The section is similar to the general MODBUS RTU communication setup. The only new field is the sensor address.

The changes of settings in this section are not memorized and don’t change the general settings of TCW210-TH.

7.2.2.5.2. Sensor communication register setup

This part of the tool is used for check and change the status of communication registers of the sensor.

7.2.2.5.3. Sensor register check

This part of the tool is used for general sensor register check.

7.2.3. Conditions

This section is used for parameterization of trigger and alert conditions for 1-Wire and MODBUS RTU sensors.

| Sensors | | | | | | | | | If out of range | | |
|---|-------------|------|-------------------------------------|------------------------------|---------|--------|------------|----------|-------------------------------------|-------------------------------------|-------------------------------------|
| # | Description | Type | Parameter | Min. | Max. | Hys. | Multiplier | Offset | mail | trap | post |
| 1 | S1:TST1xx | 1W | Temperature, °C | -40.000 | 85.000 | 8.500 | 1.000000 | 0.000000 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 | S2 | 1W | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 3 | S3 | 1W | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 4 | S4 | 1W | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 5 | S5 | MB | Temperature, °C | -40.000 | 85.000 | 8.500 | 1.000000 | 0.000000 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| | | | Humidity, %RH | 0.000 | 100.000 | 10.000 | 1.000000 | 0.000000 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| | | | Dew point, °C | 0.000 | 25.000 | 2.500 | | | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| 6 | S6 | MB | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 7 | S7 | MB | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 8 | S8 | MB | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | --- | --- | --- | --- | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Notification in case of a sensor communication lost | | | | | | | | | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Return notification | | | <input checked="" type="checkbox"/> | Notification delay (seconds) | | | 5 | (0-3600) | | | |

For every sensor, a description up to 15 characters can be set.

For all sensors “Offset” field is enabled. The offset is used for simple correction of displayed value.

For all Modbus RTU sensors multiplier is enabled, but for Teracom sensors it should be 1.

For every parameter, there is a field for trigger conditions (“Min”, “Max” and “Hys.”).

“Min” and “Max” indicate the border of the working range for the observed parameter.

A “Max” trigger condition occurs when the value exceeds the trigger set point. A “Min” trigger condition occurs when the value is lower than the trigger set point. In both cases, the monitored parameter goes out of range.

Coming back in range for the observed parameter is considered when the value goes higher than (Min + Hys) or lower than (Max – Hys). Hysteresis (“Hys”) is used to prevent excessively triggering when the value vacillates around trigger point.

Example:

TCW210-TH and TST103 are used to monitoring of room temperature. The wanted minimum temperature is 19°C. The initial temperature is 17°C.

TST100 is assigned to the first position for 1-Wire sensors.


Following parameters are set for Sensor1: Min=19, Max=85 and Hys=0.5.

| Sensors | | | | | | | | | If out of range | | |
|---------|-------------|------|-----------------|--------|--------|-------|------------|----------|-------------------------------------|-------------------------------------|-------------------------------------|
| # | Description | Type | Parameter | Min. | Max. | Hys. | Multiplier | Offset | mail | trap | post |
| 1 | S1:TST1xx | 1W | Temperature, °C | 19.000 | 85.000 | 0.500 | 1.000000 | 0.000000 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

When the controller is switched on, Alarm is immediately activated because the monitored temperature is out of range.

When the temperature reaches 19.5°C (19.0 + 0.5) it goes in range (trigger condition) and Alarm is deactivated.

The temperature falls and when it reached 19°C it goes out of range (trigger and alert conditions). E-mail is sent.




The “Max” value is set far enough from the wanted temperature to avoid trigger/alert conditions around it.

For every sensor, there are 3 independent ways of alert for alarm condition – e-mail, SNMP trap and HTTP/HTTPS post of an XML/JSON file. Each alarm notification method is activated by a checkbox.

In case of sensors communication loss e-mail, SNMP trap and post (HTTP/HTTPS post of XML file) notification can be send. Each notification method is activated by a checkbox.

Globally for all sensors, there is a checkbox “Return notification”. If this option is chosen there will be notification also when parameter returns in range.

Globally for all sensors, there are “Notification delay” parameter. It is very useful as a filter for short alarm conditions.



7.2.4. System

On this page, some general settings can be made.

7.2.4.1. General

The system name, location, and contact can be used for automatic identification of device via M2M protocols.

| General | |
|-----------------|--|
| System name | <input type="text" value="Name"/> |
| System location | <input type="text" value="Location"/> |
| System contact | <input type="text" value="info@teracom.cc"/> |

7.2.4.2. WEB access

In this section, WEB access authentication can be deactivated. By default, it is activated with admin/admin authentication details.

HTTP port for WEB access can be changed. This is useful for some routers which don't support different outside/inside ports for port forwarding. By default, HTTP port is 80.

| Web access | |
|----------------|-------------------------------------|
| Authentication | <input type="text" value="Enable"/> |
| HTTP port | <input type="text" value="80"/> |

7.2.4.3. HTTP API

In this section, HTTP API access authentication can be activated/deactivated. By default it is active.

| HTTP API | |
|----------------|-------------------------------------|
| Authentication | <input type="text" value="Enable"/> |

Authentication details are the same for WEB access. The controller support two types of authentication – see the explanation for HTTP API below.

7.2.4.4. Monitoring page automatic refresh

Monitoring page refresh interval can be set between 0 and 253 seconds. Zero means no automatic refresh.

| Monitoring page automatic refresh | |
|-----------------------------------|--|
| Interval (seconds) | <input type="text" value="1"/> (0-253) |

7.2.4.5. Display

The unit for observed temperatures can be selected between Celsius and Fahrenheit temperature scales.

If all sensors are attached to the one interface, the other section can be removed from the Monitoring page by the appropriate checkbox.

| Display | |
|-------------------|--------------------------------------|
| Temperature units | <input type="text" value="Celsius"/> |
| 1-Wire sensors | <input checked="" type="checkbox"/> |
| Modbus sensors | <input checked="" type="checkbox"/> |

7.2.5. Time

Internal RTC (Real Time clock) of the controller can be set either manually or automatically.

| Time setup | |
|--------------------|----------------------|
| Time configuration | NTP server |
| NTP server IP/URL | time.google.com |
| Time zone | +3.00 |
| Interval (h) | 12 |
| If not found (h) | 1 |
| Set time | 18.04.2018, 16:40:30 |
| Uptime | |
| Uptime | 13days,06:05:00 |

| | |
|--------------|----------------------|
| Current time | 18.04.2018, 16:40:34 |
| Last updated | 18.04.2018, 16:40:15 |
| Status | OK |
| Delay (ms) | 43.3m5 |
| Stratum | 1 |

For automatic clock synchronization, the controller supports NTP (Network Time Protocol) and all necessary parameters for automatic synchronization are available in this section.

By default, NTP synchronization is disabled, server – time.google.com, Time zone +0.00 and interval of 12 hours.

7.3. Services

7.3.1. MODBUS

TCW210-TH supports MODBUS TCP/IP over the Ethernet interface.

| Modbus TCP/IP | |
|---------------|--------|
| Modbus | Enable |
| Port | 502 |

By default, MODBUS TCP/IP is disabled. The standard port for this protocol is 502. The table with the registers' addresses can be found in section 8.3. MODBUS TCP/IP.

7.3.2. SMTP

This page is used to enter valid SMTP settings for email alerts and recipients' addresses.

7.3.2.1. SMTP setup

| SMTP setup | |
|------------------------------|----------------------------|
| Mail server IP/URL | mail.teracomsystems.com |
| Mail server port | 465 |
| Type of encrypted connection | TLS |
| Sender e-mail | support@teracomsystems.com |
| Username | support@teracomsystems.com |
| Password | |

The mail server address can be set either by hostname (for example mail.teracomsystems.com) or IP address.

By default, without an encrypted connection, the SMTP port is 25. Ask ISP if the default port doesn't work.

Sender e-mail, username, and password are standard authentication details. For most SMTP servers, the sender's e-mail and username are the same.

There is a button for server settings test with feedback. In this test sender and recipient of the e-mail are the same.

Transport Layer Security protocol is used for secure communication with public mail servers. TCW220 supports TLS 1.0, TLS 1.1, and TLS 1.2 with RSA as a key exchange/agreement and authentication, which ensures successful operation with almost all public servers. STARTTLS is not supported.

7.3.2.2. Alarm destination

| Alarm destinations | | |
|---|--|-------------------------------------|
| Recipient e-mail | <input type="text" value="info@teracomsystems.com"/> | <input checked="" type="checkbox"/> |
| Recipient e-mail | <input type="text"/> | <input type="checkbox"/> |
| Recipient e-mail | <input type="text"/> | <input type="checkbox"/> |
| Recipient e-mail | <input type="text"/> | <input type="checkbox"/> |
| Recipient e-mail | <input type="text"/> | <input type="checkbox"/> |
| <input type="button" value="Test email"/> | | |

Up to 5 mail recipients can be set. All they can be activated independently by a checkbox.

7.3.2.3. E-mail details

The subject, body header, body and body footer can be customized. For this customization, a set of keys is used. All they are described on the page.

| Email details | |
|---|--|
| Subject | <input type="text" value="Att. to #C"/> |
| Body header | <input type="text" value="From #N, located at #L"/> |
| Body | <input type="text" value="#S,#D=#V#U in #T"/> |
| Body footer | <input type="text" value="IP Address:#A, MAC Address:#M"/> |
| Subject, header and footer variables | Body variables |
| #N System Name | #D Sensor Description |
| #L System Location | #V Measured Value |
| #C System Contact | #U Unit of measured value |
| #A IP Address of device | #T Time stamp of message |
| #M MAC address of device | #S Status of parameter-ALARM/NORMAL |
| #H Hostname | #I ID of message |
| | #W LoW limit |
| | #G HiGh limit |

7.3.3. SNMP

The TCW210-TH supports SNMP v.2.

In this section, all necessary parameters for proper operation of SNMP can be set.

The screenshot shows the 'SNMP setup' and 'SNMP traps' configuration sections. The 'SNMP setup' section includes a dropdown for 'SNMP' (set to 'Enable'), a text field for 'SNMP port' (161), a text field for 'Read community' (public), and a text field for 'Write community' (private). The 'SNMP traps' section contains a table with five rows, each representing a trap recipient. Each row has fields for IP, Port, Community, a status dropdown (all set to 'Disable'), and a 'Test' button.

| SNMP setup | | | | | |
|-----------------|---------|--|--|--|--|
| SNMP | Enable | | | | |
| SNMP port | 161 | | | | |
| Read community | public | | | | |
| Write community | private | | | | |

| SNMP traps | | | | | | | |
|------------|---------------|------|-----|-----------|--------|---------|------|
| IP | 192.168.32.32 | Port | 162 | Community | public | Disable | Test |
| IP | 0.0.0.0 | Port | 162 | Community | public | Disable | Test |
| IP | 0.0.0.0 | Port | 162 | Community | public | Disable | Test |
| IP | 0.0.0.0 | Port | 162 | Community | public | Disable | Test |
| IP | 0.0.0.0 | Port | 162 | Community | public | Disable | Test |

By default SNMP is disabled, the port is 161, read community is public and write community is private.

In an alarm condition, SNMP trap can be sent up to 5 independent recipients. All they can be with different port and community. There is an independent button for trap test. SNMP traps can be sent if:

- the measured parameter of the sensor goes outside the range;
- restart;
- SW reset.

7.3.4. Logger

The TCW210-TH supports logger for all monitored parameters. The records are made in a circular buffer within the internal flash memory. When the buffer is full, the oldest values are overwritten with the newest ones.

7.3.4.1. Logger

The screenshot shows the 'Logger setup' and 'HTTP upload setup' configuration sections. The 'Logger setup' section includes dropdowns for 'Logger' (Enable), 'Logger mode' (Time mode), and 'Logger record sync' (Enable). It also has text fields for 'Log interval (seconds)' (60), 'Sync to the minute' (0), and a dropdown for 'Log interval (minutes)' (15). The 'HTTP upload setup' section includes dropdowns for 'HTTP upload' (Enable) and 'Protocol' (https), a text field for 'Server' (http(s)://www.teracomsystems:443/temp/TCW220/logs/postlog.php), a dropdown for 'Upload interval (h)' (1h), and a text field for 'Sync time' (00:00:00). At the bottom, there are three buttons: 'Upload test log', 'Force upload', and 'Download full log'.

| Logger setup | |
|------------------------|--------------|
| Logger | Enable |
| Logger mode | Time mode |
| Logger record sync | Enable |
| Log interval (seconds) | 60 (10-3600) |
| Sync to the minute | 0 (00-59) |
| Log interval (minutes) | 15 |

| HTTP upload setup | |
|---------------------|---|
| HTTP upload | Enable |
| Protocol | https |
| Server | http(s)://www.teracomsystems:443/temp/TCW220/logs/postlog.php |
| Upload interval (h) | 1h |
| Sync time | 00:00:00 |

Upload test log
Force upload
Download full log

The logger works in three modes – Time, Alarm and Time&Alarm. The mode specifies what initiates a record in the logger’s memory.

In Time mode, records are made periodically on “Log interval” time. In Alarm mode, records are made on every alarm condition. In Time&Alarm mode, a mix of both conditions for records is used.

The log interval determines the time between two log entries. It is good to remember that by reducing the log interval, we increase the resolution, but we also reduce the past period for which we have records.

The logger records can be synchronized with a specific minute in an hour. Synchronization is very useful when monitoring electricity, water, gas meters, etc. The log interval can be chosen from a drop-down menu between 1 and 60 minutes. The field „Sync to the minute“ determines which minute of every hour is used for synchronization. Although any minute can be selected, it is better to use the default value - 00.

Example:

The current settings are:

- Current time = 09:12
- Logger record sync = Enable;
- Sync to the minute = 00;
- Sync interval = 15 minutes.

The settings determine 4 records per hour in **HH:00**, HH:15, HH:30, and HH:45.

The device is powered up.

The first record will be immediately after power-up - 09:12. The next records will be in 09:15, 09:30, 09:45, 10:00, 10:15, etc.

There are two ways to reach the logger records:

- download of the full log file, using “Download full log” in the WEB interface;
- periodical upload the last unsent records to the dedicated HTTP server.

The records are uploaded in CSV file format using HTTP or HTTPS protocol. The HTTPS upload is over TLS 1.0, TLS 1.1 and TLS 1.2 with RSA as a key exchange/agreement and authentication.

The period of the upload can be chosen from the menu between 1 and 24 hours. If you enable this service, take care of the real-time clock (NTP service).

The HTTP server for upload can be domain or IP address but take care about DNS settings.

“Sync time” is a moment in the day when a period of upload is synchronized.

Example:

Current time is 19:31, Upload period is 3 hours and Sync time is 9:00.

To synchronize the logger to 9:00 it means that time for uploads will be: 09:00, 12:00, 15:00, 18:00, 21:00, 24:00, 03:00 and 06:00. The first upload, after enabling the logger in 19:31, will be in 21:00.

The button “Force upload” initiates upload recorded information between previous periodical upload and now.

By default, the logger is disabled.

More about the logger can be found in the Data logger section.

7.3.5. HTTP post

TCW210-TH can periodically upload a file to a dedicated server using HTTP or HTTPS Post.

The HTTPS is over TLS 1.0, TLS 1.1 and TLS 1.2 with RSA as a key exchange/agreement and authentication.

The posting period is between 10 and 14400 seconds.

The file format can be XML or JSON.

| HTTP post setup | |
|-----------------------|---|
| HTTP post | Enable |
| Data format | XML |
| Protocol | http |
| Server | http(s):// www.teracomsystems.com/posttest/postloop.php |
| Mode | Periodic&Alarm |
| Period (seconds) | 60 (10-14400) |
| Key | 00:00:00:00:00:22 |
| Process answer | Yes |
| Test HTTP post | |

By default, Periodic&Alarm is selected as the mode. In addition to the periodic posts, a file can be uploaded at any alarm condition.

If Periodic only is selected as the mode, then periodic posts are performed without alarm posts.

If Alarm only is selected as the mode, then alarm posts are performed without periodic posts.

The “Key” field value is sent in the XML/JSON and can be used for device identification.

If “Process Answer” option is enabled, the TCW210-TH will process the answer of the remote server. The list of valid commands is described in section “HTTP API commands”.

7.3.6. Cloud

ThingSpeak server is an open data platform and API for the Internet of Things that enables you to collect, store, analyze, visualize, and act on data from sensors.

The primary element of ThingSpeak activity is the channel, which contains API key, channel ID, and eight data fields.

TCW210-TH has four channel sections – Channel 1, Channel 2, Channel 3 and Channel 4.

| ThingSpeak setup | |
|----------------------|--------------------------|
| Enable ThingSpeak | <input type="checkbox"/> |
| Connect on any alarm | <input type="checkbox"/> |
| Period (sec) | 300 |
| Link | |
| Channel 1 | |
| Enable | <input type="checkbox"/> |
| API key | |
| Channel ID | 1 |
| Field 1 | S1:TST1xx Temperature |
| Field 2 | S2:TSH2xx Temperature |
| Field 3 | S2:TSH2xx Temperature |
| Field 4 | S4:TST3xx Temperature |
| Field 5 | S5:TST3xx Temperature |
| Field 6 | S6:TST3xx Temperature |
| Field 7 | S7:TSH3xx Temperature |
| Field 8 | none |
| Test | |

7.3.7. Dynamic DNS

With dynamic DNS can access TCW210-TH from the public Internet without investing in a broadband account that has a static IP address.

TCW210-TH supports the following DNS services – DynDNS, No-IP, and DNS-O-Matric.

| Dynamic DNS setup | |
|-------------------|--------------------------|
| Dynamic DNS | Enable |
| Service | DynDNS |
| Hostname | tcw210-th.dyndns.org |
| User | teracomtcw |
| Password | ***** |
| Maintainer e-mail | teracom_test@yahoo.com |
| DDNS last status | The service is disabled. |

7.4. Administration

7.4.1. User/Pass

The screenshot displays two sections for user configuration. The first section, titled "Admin access", contains three input fields: "Username" with the value "admin", "Password", and "Confirm password". Below these fields is a "SAVE" button. The second section, titled "User access", also contains three input fields: "Username" with the value "user", "Password", and "Confirm password". Below these fields is another "SAVE" button.

The TCW210-TH supports two users – “Admin” and “User”.

“Admin” has administrative rights.

“User” shall not modify any settings.

The username and password can be up to 31 characters long.

7.4.2. Backup/Restore

TCW210-TH supports backup and restore of all user setting. All settings are saved in XML backup file. This file can be used after this for restore on many devices. This is very useful for multiplying similar settings to a batch of controllers.

The screenshot shows the "Backup/Restore configuration" section. It features a "Select configuration file" label, a "Choose File" button, and the text "No file chosen". Below this are two buttons: "RESTORE" and "BACKUP".

7.4.3. FW update

The TCW210-TH can be updated via the WEB interface.

The screenshot displays the "Firmware update" section. It shows the "Current FW version" as "TCW210TH-v1.208". Below this is a "Select FW version" label, a "Choose File" button, and the text "No file chosen". At the bottom of the section is an "UPLOAD" button.

To update the device follow the steps below:

- Go to www.teracomsystems.com and download the latest firmware;
- From Administration->FW update select downloaded .cod file and press “upload” button;
- After the firmware update is completed, the Login page will appear.

Attention! Don’t turn off the power supply during the update. Turning off the power supply will damage the device.

7.5. Logout

The TCW210-TH support multiseession, but the good practice is to log out after finish the work.

8. Protocols and API

8.1. SNMP

Simple Network Management Protocol (SNMP) is a standard internet protocol for managing devices on IP networks. In typical uses of SNMP, one or more administrative computers, called managers, monitor and control devices on LAN. Each controlled device, at all times, executes a software component called an agent which reports information via SNMP to the manager.

The TCW210-TH can be configured and monitored through SNMP.

This could be done using every SNMP v.2 compatible program. Parameters that can be changed, are grouped according to their functions in the tables below. To obtain a valid OID number it is necessary to replace the "x" symbol with "1.3.6.1.4.1.38783".

To save the changes configurationSaved (OID x.2.3.5.0) should be set to "1".

product

| OID | Name | Access | Description | Syntax |
|-----------|---------|-----------|------------------|---------------|
| x.4.1.1.0 | name | read-only | Device name | DisplayString |
| x.4.1.2.0 | version | read-only | Firmware version | DisplayString |
| x.4.1.3.0 | date | read-only | Release date | DateAndTime |

setup -> network

| OID | Name | Access | Description | Syntax |
|-------------|----------|-----------|---------------------------------|---------------|
| x.4.2.1.1.0 | deviceID | read-only | Device ID (default MAC address) | MacAddress |
| x.4.2.1.2.0 | hostName | read-only | Hostname | DisplayString |
| x.4.2.1.3.0 | deviceIP | read-only | Device IP address | IpAddress |

setup -> io -> sensorsSetup -> sensor1setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.1.1.0 | s1description | read-write | Sensor 1 description | DisplayString |
| x.4.2.2.1.1.2.1.0 | s11MAXInt | read-write | S11 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.2.2.0 | s11MINInt | read-write | S11 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.2.3.0 | s11HYSTInt | read-write | S11 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.2.4.0 | s11MULTInt | read-write | S11 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.2.5.0 | s11OFFSETInt | read-write | S11 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.3.1.0 | s12MAXInt | read-write | S12 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.3.2.0 | s12MINInt | read-write | S12 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.3.3.0 | s12HYSTInt | read-write | S12 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.3.4.0 | s12MULTInt | read-write | S12 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.3.5.0 | s12OFFSETInt | read-write | S12 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.4.1.0 | s13MAXInt | read-write | S13 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.4.2.0 | s13MINInt | read-write | S13 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.1.4.3.0 | s13HYSTInt | read-write | S13 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor2setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.2.1.0 | s2description | read-write | Sensor2 description | DisplayString |
| x.4.2.2.1.2.2.1.0 | s21MAXInt | read-write | s21 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.2.2.0 | s21MINInt | read-write | S21 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.2.3.0 | s21HYSTInt | read-write | S21 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.2.4.0 | s21MULTInt | read-write | S21 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.2.5.0 | s21OFFSETInt | read-write | S21 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.3.1.0 | s22MAXInt | read-write | S22 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.3.2.0 | s22MINInt | read-write | S22 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.3.3.0 | s22HYSTInt | read-write | S22 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.3.4.0 | S22MULTInt | read-write | S22 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.3.5.0 | s22OFFSETInt | read-write | S22 offset value x1000 in Integer format | Integer32 |

| | | | | |
|-------------------|------------|------------|--|-----------|
| x.4.2.2.1.2.4.1.0 | s23MAXInt | read-write | S23 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.4.2.0 | s23MINInt | read-write | S23 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.2.4.3.0 | s23HYSTInt | read-write | S23 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor3setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.3.1.0 | s3description | read-write | Sensor 3 description | DisplayString |
| x.4.2.2.1.3.2.1.0 | s31MAXInt | read-write | S31 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.2.2.0 | s31MINInt | read-write | S31 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.2.3.0 | s31HYSTInt | read-write | S31 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.2.4.0 | s31MULTInt | read-write | S31 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.2.5.0 | s31OFFSETInt | read-write | S31 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.3.1.0 | s32MAXInt | read-write | S32 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.3.2.0 | s32MINInt | read-write | S32 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.3.3.0 | s32HYSTInt | read-write | S32 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.3.4.0 | s32MULTInt | read-write | S32 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.3.5.0 | s32OFFSETInt | read-write | S32 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.4.1.0 | s33MAXInt | read-write | S33 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.4.2.0 | s33MINInt | read-write | S33 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.3.4.3.0 | s33HYSTInt | read-write | S33 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor4setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.4.1.0 | s4description | read-write | Sensor 4 description | DisplayString |
| x.4.2.2.1.4.2.1.0 | s41MAXInt | read-write | S41 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.2.2.0 | s41MINInt | read-write | S41 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.2.3.0 | s41HYSTInt | read-write | S41 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.2.4.0 | s41MULTInt | read-write | S41 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.2.5.0 | s41OFFSETInt | read-write | S41 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.3.1.0 | s42MAXInt | read-write | S42 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.3.2.0 | s42MINInt | read-write | S42 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.3.3.0 | s42HYSTInt | read-write | S42 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.3.4.0 | s42MULTInt | read-write | S42 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.3.5.0 | s42OFFSETInt | read-write | S42 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.4.1.0 | s43MAXInt | read-write | S43 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.4.2.0 | s43MINInt | read-write | S43 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.4.4.3.0 | s43HYSTInt | read-write | S43 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor5setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.5.1.0 | s5description | read-write | Sensor 5 description | DisplayString |
| x.4.2.2.1.5.2.1.0 | s51MAXInt | read-write | S51 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.2.2.0 | s51MINInt | read-write | S51 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.2.3.0 | s51HYSTInt | read-write | S51 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.2.4.0 | s51MULTInt | read-write | S51 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.2.5.0 | s51OFFSETInt | read-write | S51 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.3.1.0 | s52MAXInt | read-write | S52 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.3.2.0 | s52MINInt | read-write | S52 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.3.3.0 | s52HYSTInt | read-write | S52 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.3.4.0 | s52MULTInt | read-write | S52 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.3.5.0 | s52OFFSETInt | read-write | S52 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.4.1.0 | s53MAXInt | read-write | S53 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.4.2.0 | s53MINInt | read-write | S53 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.5.4.3.0 | s53HYSTInt | read-write | S53 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor6setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.6.1.0 | s6description | read-write | Sensor 6 description | DisplayString |
| x.4.2.2.1.6.2.1.0 | s61MAXInt | read-write | S61 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.2.2.0 | s61MINInt | read-write | S61 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.2.3.0 | s61HYSTInt | read-write | S61 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.2.4.0 | s61MULTInt | read-write | S61 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.2.5.0 | s61OFFSETInt | read-write | S61 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.3.1.0 | s62MAXInt | read-write | S62 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.3.2.0 | s62MINInt | read-write | S62 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.3.3.0 | s62HYSTInt | read-write | S62 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.3.4.0 | s62MULTInt | read-write | S62 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.3.5.0 | s62OFFSETInt | read-write | S62 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.4.1.0 | s63MAXInt | read-write | S63 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.4.2.0 | s63MINInt | read-write | S63 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.6.4.3.0 | s63HYSTInt | read-write | S63 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor7setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.7.1.0 | s7description | read-write | Sensor 7 description | DisplayString |
| x.4.2.2.1.7.2.1.0 | s71MAXInt | read-write | S71 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.2.2.0 | s71MINInt | read-write | S71 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.2.3.0 | s71HYSTInt | read-write | S71 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.2.4.0 | s71MULTInt | read-write | S71 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.2.5.0 | s71OFFSETInt | read-write | S71 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.3.1.0 | s72MAXInt | read-write | S72 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.3.2.0 | s72MINInt | read-write | S72 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.3.3.0 | s72HYSTInt | read-write | S72 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.3.4.0 | s72MULTInt | read-write | S72 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.3.5.0 | s72OFFSETInt | read-write | S72 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.4.1.0 | s73MAXInt | read-write | S73 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.4.2.0 | s73MINInt | read-write | S73 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.7.4.3.0 | s73HYSTInt | read-write | S73 hysteresis value x1000 in Integer format | Integer32 |

setup -> io -> sensorsSetup -> sensor8setup

| OID | Name | Access | Description | Syntax |
|-------------------|---------------|------------|--|---------------|
| x.4.2.2.1.8.1.0 | s8description | read-write | Sensor 8 description | DisplayString |
| x.4.2.2.1.8.2.1.0 | s81MAXx10Int | read-write | S81 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.2.2.0 | s81MINx10Int | read-write | S81 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.2.3.0 | s81HYSTx10Int | read-write | S81 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.2.4.0 | s81MULTInt | read-write | S81 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.2.5.0 | s81OFFSETInt | read-write | S81 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.3.1.0 | s82MAXx10Int | read-write | S82 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.3.2.0 | s82MINx10Int | read-write | S82 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.3.3.0 | s82HYSTx10Int | read-write | S82 hysteresis value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.3.4.0 | s82MULTInt | read-write | S82 multiplier value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.3.5.0 | s82OFFSETInt | read-write | S82 offset value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.4.1.0 | s83MAXx10Int | read-write | S83 maximum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.4.2.0 | s83MINx10Int | read-write | S83 minimum value x1000 in Integer format | Integer32 |
| x.4.2.2.1.8.4.3.0 | s83HYSTx10Int | read-write | S83 hysteresis value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor1

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|------------------------------|
| x.4.3.1.1.1.0 | s11Int | read-only | S11 value x1000 in Integer format | Integer32 |
| x.4.3.1.1.2.0 | s12Int | read-only | S12 value x1000 in Integer format | Integer32 |
| x.4.3.1.1.3.0 | s13Int | read-only | S13 value x1000 in Integer format | Integer32 |
| x.4.3.1.1.4.0 | s1ID | read-only | S1 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.1.5.1.0 | s11Al | read-only | S11 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.1.5.2.0 | s12Al | read-only | S12 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.1.5.3.0 | s13Al | read-only | S13 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.1.6.0 | s11RawInt | read-only | S11 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.1.7.0 | s12RawInt | read-only | S12 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor2

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|------------------------------|
| x.4.3.1.2.1.0 | s21Int | read-only | S21 value x1000 in Integer format | Integer32 |
| x.4.3.1.2.2.0 | s22Int | read-only | S22 value x1000 in Integer format | Integer32 |
| x.4.3.1.2.3.0 | s23Int | read-only | S23 value x1000 in Integer format | Integer32 |
| x.4.3.1.2.4.0 | s2ID | read-only | S2 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.2.5.1.0 | s21Al | read-only | S21 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.2.5.2.0 | s22Al | read-only | S22 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.2.5.3.0 | s23Al | read-only | S23 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.2.6.0 | s21RawInt | read-only | S21 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.2.7.0 | s22RawInt | read-only | S22 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor3

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|------------------------------|
| x.4.3.1.3.1.0 | s31Int | read-only | S31 value x1000 in Integer format | Integer32 |
| x.4.3.1.3.2.0 | s32Int | read-only | S32 value x1000 in Integer format | Integer32 |
| x.4.3.1.3.3.0 | s3ID | read-only | S3 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.3.5.1.0 | s31Al | read-only | S31 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.3.5.2.0 | s32Al | read-only | S32 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.3.5.3.0 | s33Al | read-only | S33 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.3.6.0 | s31RawInt | read-only | S31 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.3.7.0 | s32RawInt | read-only | S32 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor4

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|------------------------------|
| x.4.3.1.4.1.0 | s41Int | read-only | S41 value x1000 in Integer format | Integer32 |
| x.4.3.1.4.2.0 | s42Int | read-only | S42 value x1000 in Integer format | Integer32 |
| x.4.3.1.4.3.0 | s43Int | read-only | S43 value x1000 in Integer format | Integer32 |
| x.4.3.1.4.3.0 | s4ID | read-only | S4 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.4.5.1.0 | s41Al | read-only | S41 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.4.5.2.0 | s42Al | read-only | S42 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.4.5.3.0 | s43Al | read-only | S43 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.4.6.0 | s41RawInt | read-only | S41 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.4.7.0 | s42RawInt | read-only | S42 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor5

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|---------------------------------|
| x.4.3.1.5.1.0 | s51Int | read-only | S51 value x1000 in Integer format | Integer32 |
| x.4.3.1.5.2.0 | s52Int | read-only | S52 value x1000 in Integer format | Integer32 |
| x.4.3.1.5.3.0 | s53Int | read-only | S53 value x1000 in Integer format | Integer32 |
| x.4.3.1.5.4.0 | s5ID | read-only | S5 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.5.5.1.0 | s51Al | read-only | S51 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.5.5.2.0 | s52Al | read-only | S52 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.5.5.3.0 | s53Al | read-only | S53 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.5.6.0 | s51RawInt | read-only | S51 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.5.7.0 | s52RawInt | read-only | S52 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor6

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|---------------------------------|
| x.4.3.1.6.1.0 | s61Int | read-only | S61 value x1000 in Integer format | Integer32 |
| x.4.3.1.6.2.0 | s62Int | read-only | S62 value x1000 in Integer format | Integer32 |
| x.4.3.1.6.3.0 | s63Int | read-only | S63 value x1000 in Integer format | Integer32 |
| x.4.3.1.6.4.0 | s6ID | read-only | S6 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.6.5.1.0 | s61Al | read-only | S61 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.6.5.2.0 | s62Al | read-only | S62 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.6.5.3.0 | s63Al | read-only | S63 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.6.6.0 | s61RawInt | read-only | S61 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.6.7.0 | s62RawInt | read-only | S62 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor7

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|---------------------------------|
| x.4.3.1.7.1.0 | s71Int | read-only | S71 value x1000 in Integer format | Integer32 |
| x.4.3.1.7.2.0 | s72Int | read-only | S72 value x1000 in Integer format | Integer32 |
| x.4.3.1.7.3.0 | s73Int | read-only | S73 value x1000 in Integer format | Integer32 |
| x.4.3.1.7.4.0 | s7ID | read-only | S7 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.7.5.1.0 | s71Al | read-only | S71 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.7.5.2.0 | s72Al | read-only | S72 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.7.5.3.0 | s73Al | read-only | S73 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.7.6.0 | s71RawInt | read-only | S71 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.7.7.0 | s72RawInt | read-only | S72 raw value x1000 in Integer format | Integer32 |

monitorNcontrol -> sensors -> sensor8

| OID | Name | Access | Description | Syntax |
|-----------------|-----------|-----------|---------------------------------------|---------------------------------|
| x.4.3.1.8.1.0 | s81Int | read-only | S81 value x1000 in Integer format | Integer32 |
| x.4.3.1.8.2.0 | s82Int | read-only | S82 value x1000 in Integer format | Integer32 |
| x.4.3.1.8.3.0 | s83Int | read-only | S83 value x1000 in Integer format | Integer32 |
| x.4.3.1.8.4.0 | s8ID | read-only | S8 ID value | OCTET STRING (SIZE (16)) |
| x.4.3.1.8.5.1.0 | s81Al | read-only | S81 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.8.5.2.0 | s82Al | read-only | S82 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.8.5.3.0 | s83Al | read-only | S83 alarm status | INTEGER {normal(0),alarm(1)} |
| x.4.3.1.8.6.0 | s81RawInt | read-only | S81 raw value x1000 in Integer format | Integer32 |
| x.4.3.1.8.7.0 | s82RawInt | read-only | S82 raw value x1000 in Integer format | Integer32 |

monitorNcontrol

| OID | Name | Access | Description | Syntax |
|-----------|--------------------|------------|---|--|
| x.4.3.5.0 | configurationSaved | read-write | Configuration save status SAVED/UNSAVED | INTEGER { unsaved(0), saved(1) } |
| x.4.3.6.0 | restartDevice | read-write | Restart Device | INTEGER { cancel(0), restart(1) } |
| x.4.3.7.0 | temperatureUnit | read-only | Unit of the all temperature values | INTEGER { celcius(0), fahrenheit(1) } |
| x.4.3.8.0 | hardwareErr | read-only | Hardware Error | INTEGER { noErr(0), owErr(1), hwErr(2) } |


8.2. HTTP API

8.2.1. HTTP Post

TCW210-TH can execute HTTP/HTTPS Post to upload XML/JSON file to a dedicated server.

This functionality is very useful if the controller is behind the router without public IP address or the user don't have access to router configuration. The server should have a public IP address.

The typical monitoring application is shown in the picture below:



HTTP/HTTPS post can be sent periodically or periodically plus on an alarm condition.

To test HTTP/HTTPS Post follow the steps below:

- Save following code like post.php:

```
<?php
define("FILENAME", 'status.xml');
define("FOLDER", "");
define("SEPARATOR", "");
define("STR_SUCCESS", 'set FIN');
define("STR_ERROR", 'error');

if($_SERVER['REQUEST_METHOD'] == 'POST'){
    $datePrefix = date('YmdHis', strtotime('now'));
    $pathname = FOLDER.SEPARATOR.$datePrefix.'_' .FILENAME;
    $postdata = file_get_contents("php://input");
    $handle = fopen($pathname, 'w+');
    $content = var_export($postdata, true);
    fwrite($handle, substr($content, 1, strlen($content)-2));
    fclose($handle);
    echo (($handle === false) ? STR_ERROR : STR_SUCCESS)."\r\n";
}
else {
    echo "The PHP script is working!";
}
?>
```

- Copy the post.php file on a public web server with PHP support. To verify that the script is working properly, you can type the URL in your web browser (for example www.yourserverURL.com/post.php). If all is OK, a web page with “The PHP script is working!” will be shown.
- Set the controller to send an HTTP/HTTPS POST to your web server. Enter the address (yourserverURL.com/post.php) in the URL field. Click on “Test HTTP Post” button.
- If the HTTP/HTTPS POST is received and processed, “OK” will be shown close to the button. Along with this, an XML file will be created in the same directory, where post.php is located. The file name will contain time information and looks like 20171120103318_status.xml.

8.2.2. HTTP Get

HTTP Get can be used to monitor TCW210-TH via XML or JSON files. The format is as follows:

`http://device.ip.address/status.xml`

`http://device.ip.address/status.json`

See sections **8.2.4 XML file structure** and **8.2.5 JSON file structure** for details of files.

HTTP Get can be sent at any time to TCW210-TH if it is on the same network or it has appropriate routing.

If there isn't direct access to the device, HTTP Get can be sent immediately after HTTP Post receiving from the same device.

8.2.2.1. Commands

All command used with HTTP Post can be used also with HTTP Get. The right format is:

`http://device.ip.address/status.xml?yyy=xxx`

Where:

yyy is the command;

xxx is the parameter.

Example:

`http://device.ip.address/status.xml?pper=120` will set post period of 120 sec.

8.2.2.2. HTTP GET authentication

If HTTP API authentication is enabled, basic access authentication is required to access the status.xml file. The format of the command is shown in the table below:

| XML/HTTP API authentication | Format |
|-----------------------------|--|
| enabled | <code>http://device.ip.address/status.xml?a=uuuu:pppp</code> |
| disabled | <code>http://device.ip.address/status.xml</code> |

Example:

`http://device.ip.address/status.xml?a=admin:admin&pper=120` will set post period of 120 sec in case the username=admin and pass=admin

8.2.3. List of HTTP API commands

| Command | Description |
|------------------------|--|
| <code>snpt=30.0</code> | Set Min of sensor to 30.0 (p is 1,2,3,4,5,6,7 or 8 for the respective sensor t is 1 or 2 for the respective parameter of sensor) <code>sn12=30.0</code> will set Min for sensor 1, parameter 2 |
| <code>sxpt=40.0</code> | Set Max of sensor to 40.0 (p is 1,2,3,4,5,6,7 or 8 for the respective sensor t is 1 or 2 for the respective parameter of sensor) <code>sx42=40.0</code> will set Min for sensor 4, parameter 2 |

| | |
|-------------|---|
| sypt=2.0 | Set Hys of sensor to 2.0 (p is 1,2,3,4,5,6,7 or 8 for the respective sensor t is 1 or 2 for the respective parameter of sensor) sy81=2.0 will set Hys for sensor 8, parameter 1 |
| delsen=xxxx | Notification delay for sensors (xxxx is between 0 and 3600) |
| dataf=x | Data format XML/JSON for HHTP Post – 0 XML, 1 JSON |
| pushtls=x | http(s) protocol, where x is 0 for http and 1 for https |
| purl=yyy | URL for HTTP Post to Server 1, where yyy is a full path to php file. Example: purl=212.25.45.120:30181/xampp/test/posttest.php |
| pper=x | HTTP Post period in seconds (x is between 10 and 14400) |
| dk=xxx | HTTP Post key – xxx is up to 17 characters |
| save | Save all previous changes (except relays' one) in the FLASH memory. As every save reflects the FLASH cycles (endurance), this command should be used very carefully. pper=120&save – will set Post period to 120 seconds and save it |
| FIN | Terminate session. (It works with HTTP/HTTPS Post, but not with HTTP Get.) |

8.2.4. XML file structure

```

<Monitor>
  <DeviceInfo>
    <DeviceName>TCW210-TH</DeviceName>
    <HostName>TCW210TH</HostName>
    <ID>54:10:EC:0C:1D:E1</ID>
    <FwVer>TCW210TH-v1.252</FwVer>
    <MnflInfo>www.teracomsystems.com</MnflInfo>
    <SysContact>info@teracomsystems.com</SysContact>
    <SysName>SysName</SysName>
    <SysLocation>SysLocation</SysLocation>
  </DeviceInfo>
  <S>
    <S1>
      <description>S1:TST1xx</description>
      <id>2867895F07000058</id>
      <SenType>1W</SenType>
      <addr>---</addr>
      <item1>
        <value>22.875</value>
        <unit>°C</unit>
        <alarm>0</alarm>
        <min>19.000</min>
        <max>85.000</max>
        <hys>0.500</hys>
      </item1>
      <item2>
        <value>---</value>
        <unit>---</unit>
    </S1>
  </S>

```

```

        <alarm>0</alarm>
        <min>---</min>
        <max>---</max>
        <hys>---</hys>
    </item2>
    <item3>
        <value>---</value>
        <unit>---</unit>
        <alarm>0</alarm>
        <min>---</min>
        <max>---</max>
        <hys>---</hys>
    </item3>
</S1>
<S2>
    <description>S2</description>
    <id>0000000000000000</id>
    <SenType>1W</SenType>
    <addr>---</addr>
    <item1>
        <value>---</value>
        <unit>---</unit>
        <alarm>0</alarm>
        <min>---</min>
        <max>---</max>
        <hys>---</hys>
    </item1>
    <item2>
        <value>---</value>
        <unit>---</unit>
        <alarm>0</alarm>
        <min>---</min>
        <max>---</max>
        <hys>---</hys>
    </item2>
    <item3>
        <value>---</value>
        <unit>---</unit>
        <alarm>0</alarm>
        <min>---</min>
        <max>---</max>
        <hys>---</hys>
    </item3>
</S2>
<S3>
    <description>S3</description>
    <id>0000000000000000</id>
    <SenType>1W</SenType>
    <addr>---</addr>
    <item1>
        <value>---</value>
        <unit>---</unit>

```

```
<alarm>0</alarm>
<min>---</min>
<max>---</max>
<hys>---</hys>
</item1>
<item2>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item2>
<item3>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item3>
</S3>
<S4>
  <description>S4</description>
  <id>0000000000000000</id>
  <SenType>1W</SenType>
  <addr>---</addr>
  <item1>
    <value>---</value>
    <unit>---</unit>
    <alarm>0</alarm>
    <min>---</min>
    <max>---</max>
    <hys>---</hys>
  </item1>
  <item2>
    <value>---</value>
    <unit>---</unit>
    <alarm>0</alarm>
    <min>---</min>
    <max>---</max>
    <hys>---</hys>
  </item2>
  <item3>
    <value>---</value>
    <unit>---</unit>
    <alarm>0</alarm>
    <min>---</min>
    <max>---</max>
    <hys>---</hys>
  </item3>
</S4>
```

```

<S5>
  <description>S5</description>
  <id>CD00000000000000</id>
  <SenType>MB</SenType>
  <addr>1</addr>
  <item1>
    <value>22.963</value>
    <unit>°C</unit>
    <alarm>0</alarm>
    <min>-40.000</min>
    <max>85.000</max>
    <hys>8.500</hys>
  </item1>
  <item2>
    <value>31.279</value>
    <unit>%RH</unit>
    <alarm>0</alarm>
    <min>0.000</min>
    <max>100.000</max>
    <hys>10.000</hys>
  </item2>
  <item3>
    <value>5.073</value>
    <unit>°C</unit>
    <alarm>0</alarm>
    <min>0.000</min>
    <max>25.000</max>
    <hys>2.500</hys>
  </item3>
</S5>
<S6>
  <description>S6</description>
  <id>0000000000000000</id>
  <SenType>MB</SenType>
  <addr>2</addr>
  <item1>
    <value>24.742</value>
    <unit>°C</unit>
    <alarm>0</alarm>
    <min>-40.000</min>
    <max>85.000</max>
    <hys>8.500</hys>
  </item1>
  <item2>
    <value>---</value>
    <unit>---</unit>
    <alarm>0</alarm>
    <min>---</min>
    <max>---</max>
    <hys>---</hys>
  </item2>
  <item3>

```



```
<value>---</value>
<unit>---</unit>
<alarm>0</alarm>
<min>---</min>
<max>---</max>
<hys>---</hys>
</item3>
</S6>
<S7>
<description>S7</description>
<id>0000000000000000</id>
<SenType>MB</SenType>
<addr>0</addr>
<item1>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item1>
<item2>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item2>
<item3>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item3>
</S7>
<S8>
<description>S8</description>
<id>0000000000000000</id>
<SenType>MB</SenType>
<addr>0</addr>
<item1>
  <value>---</value>
  <unit>---</unit>
  <alarm>0</alarm>
  <min>---</min>
  <max>---</max>
  <hys>---</hys>
</item1>
<item2>
```

```

        <value>----</value>
        <unit>----</unit>
        <alarm>0</alarm>
        <min>----</min>
        <max>----</max>
        <hys>----</hys>
    </item2>
    <item3>
        <value>----</value>
        <unit>----</unit>
        <alarm>0</alarm>
        <min>----</min>
        <max>----</max>
        <hys>----</hys>
    </item3>
</S8>
</S>
<HTTPPush>
    <Key/>
    <PushPeriod>300</PushPeriod>
</HTTPPush>
<hwerr/>
<Alarmed>0</Alarmed>
<Scannig/>
<Time>
    <Date>11.10.2023</Date>
    <Time>08:45:18</Time>
</Time>
</Monitor>

```

Where:

<value>----</value> and <unit>----</unit> means no sensor on this position;

<alarm>1</alarm> means there is trigger condition.

8.2.5. JSON file structure

```

{
  "Monitor": {
    "DeviceInfo": {
      "DeviceName": "TCW210-TH",
      "HostName": "TCW210TH",
      "ID": "54:10:EC:0C:1D:E1",
      "FwVer": "TCW210TH-v1.252",
      "MnflInfo": "www.teracomsystems.com",
      "SysContact": "info@teracomsystems.com",
      "SysName": "SysName",
      "SysLocation": "SysLocation"
    },
    "S": {
      "S1": {
        "description": "S1:TST1xx",
        "id": "2867895F07000058",
        "SenType": "1W",
        "addr": "----",
        "item1": {
          "value": "23.063",
          "unit": "°C",
          "alarm": "0",
          "min": "19.000",
          "max": "85.000",
          "hys": "0.500"
        }
      }
    }
  }
}

```

```

    "item2": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    },
    "item3": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    }
  },
  "S2": {
    "description": "S2",
    "id": "0000000000000000",
    "SenType": "1W",
    "addr": "---",
    "item1": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    },
    "item2": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    },
    "item3": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    }
  },
  "S3": {
    "description": "S3",
    "id": "0000000000000000",
    "SenType": "1W",
    "addr": "---",
    "item1": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    },
    "item2": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    },
    "item3": {
      "value": "---",
      "unit": "---",
      "alarm": "0",
      "min": "---",
      "max": "---",
      "hys": "---"
    }
  }
},

```

```

"S4": {
  "description": "S4",
  "id": "0000000000000000",
  "SenType": "1W",
  "addr": "---",
  "item1": {
    "value": "---",
    "unit": "---",
    "alarm": "0",
    "min": "---",
    "max": "---",
    "hys": "---"
  },
  "item2": {
    "value": "---",
    "unit": "---",
    "alarm": "0",
    "min": "---",
    "max": "---",
    "hys": "---"
  },
  "item3": {
    "value": "---",
    "unit": "---",
    "alarm": "0",
    "min": "---",
    "max": "---",
    "hys": "---"
  }
},
"S5": {
  "description": "S5",
  "id": "CD00000000000000",
  "SenType": "MB",
  "addr": "1",
  "item1": {
    "value": "23.160",
    "unit": "°C",
    "alarm": "0",
    "min": "-40.000",
    "max": "85.000",
    "hys": "8.500"
  },
  "item2": {
    "value": "31.803",
    "unit": "%RH",
    "alarm": "0",
    "min": "0.000",
    "max": "100.000",
    "hys": "10.000"
  },
  "item3": {
    "value": "5.483",
    "unit": "°C",
    "alarm": "0",
    "min": "0.000",
    "max": "25.000",
    "hys": "2.500"
  }
},
"S6": {
  "description": "S6",
  "id": "0000000000000000",
  "SenType": "MB",
  "addr": "2",
  "item1": {
    "value": "25.125",
    "unit": "°C",
    "alarm": "0",
    "min": "-40.000",
    "max": "85.000",
    "hys": "8.500"
  },
  "item2": {
    "value": "---",
    "unit": "---",
    "alarm": "0",

```

```

        "min": "---",
        "max": "---",
        "hys": "---"
    },
    "item3": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    }
},
"S7": {
    "description": "S7",
    "id": "0000000000000000",
    "SenType": "MB",
    "addr": "0",
    "item1": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    },
    "item2": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    },
    "item3": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    }
},
"S8": {
    "description": "S8",
    "id": "0000000000000000",
    "SenType": "MB",
    "addr": "0",
    "item1": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    },
    "item2": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    },
    "item3": {
        "value": "---",
        "unit": "---",
        "alarm": "0",
        "min": "---",
        "max": "---",
        "hys": "---"
    }
}
},
"HTTPPush": {
    "Key": "",
    "PushPeriod": "300"
}

```

```
},
"hwerr": "",
"Alarmed": "0",
"Scannig": "",
"Time": {
  "Date": "11.10.2023",
  "Time": "09:00:12"
}
}
```

8.3. MODBUS TCP/IP

MODBUS TCP/IP protocol is originally published by Modicon in 1979. It is used to establish master-slave/client-server communication between intelligent devices. MODBUS TCP/IP is often used to connect a supervisory computer with remote units in supervisory control and data acquisition (SCADA) systems.

8.3.1. Codes and answers

8.3.1.1. Read Holding Registers (FC=03)

Request

This command is requesting the content of holding registers 19800.

03 4D58 0002

- 03: The Function Code 3 (read Holding Registers)
- 4D58: The Data Address of the first register requested (4D58 hex = 19800)
- 0002: The total number of registers requested. (read 2 registers each 2 byte = 4 bytes)

Response

03 04 41BD 0655

- 03: The Function Code 3 (read Sensor 1 Part 1 Holding Registers)
- 04: The number of data bytes to follow (2 registers x 2 bytes each = 4 bytes)
- 41BD 0655: 4 bytes value
- All holding registers with float value are sent in big-endian.
- In the example, the above value of 23.628 is sent.

Request

This command is requesting the content of holding registers 18100.

03 46B4 0020

- 03: Function Code 3 (read Sensor 1 description Holding Registers)
- 46B4: The Data Address of the first register requested (46B4 hex = 18100)
- 0020: The total number of registers requested (read 32 registers each 2 byte = 64 bytes)

Response

03 40 5365 6E73 6F72 3100 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000

- 03: Function Code 3 (read Holding Registers)
- 40: The number of data bytes to follow (32 registers x 2 bytes each = 64 bytes)
- 5365 6E73 6F72 3100 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
- 0000 0000 0000 0000 0000 0000 0000 0000: 64 bytes value
- All holding registers with strings are sent in big-endian.
- The answer is padded with 0.
- In the example above string “Sensor1” is sent.

8.3.1.2. Exception codes

All exceptions are signaled by adding 0x80 to the function code of the request, and following this byte by a single reason byte for example as follows:

01 Illegal function

The function code received in the query is not an allowable action for the controller.

02 Illegal data address

The data address received in the query is not an allowable address for the slave. More specifically, the combination of the reference number and transfer length is invalid. For a controller with 100 registers, a request with offset 96 and length 4 would succeed, a request with offset 96 and length 5 will generate exception 02.

8.3.2. Address table

| Parameter | FC | PDU decimal address | Data size | Data |
|-----------------------------|-------|---------------------|----------------|------|
| Number of installed sensors | 03 | 18000 | 16-bit Integer | |
| | | | | |
| Sensor 1 description | 03,16 | 18100 | 64 bytes UTF-8 | |
| Sensor 2 description | 03,16 | 18132 | 64 bytes UTF-8 | |
| Sensor 3 description | 03,16 | 18164 | 64 bytes UTF-8 | |
| Sensor 4 description | 03,16 | 18196 | 64 bytes UTF-8 | |
| Sensor 5 description | 03,16 | 18228 | 64 bytes UTF-8 | |
| Sensor 6 description | 03,16 | 18260 | 64 bytes UTF-8 | |
| Sensor 7 description | 03,16 | 18292 | 64 bytes UTF-8 | |
| Sensor 8 description | 03,16 | 18324 | 64 bytes UTF-8 | |
| | | | | |
| Sensor 1, S11 dimension | 03 | 18400 | 64 bytes UTF-8 | |
| Sensor 1, S12 dimension | 03 | 18432 | 64 bytes UTF-8 | |
| Sensor 1, S13 dimension | 03 | 18464 | 64 bytes UTF-8 | |
| Sensor 2, S21 dimension | 03 | 18496 | 64 bytes UTF-8 | |
| Sensor 2, S22 dimension | 03 | 18528 | 64 bytes UTF-8 | |
| Sensor 2, S23 dimension | 03 | 18560 | 64 bytes UTF-8 | |
| Sensor 3, S31 dimension | 03 | 18592 | 64 bytes UTF-8 | |
| Sensor 3, S32 dimension | 03 | 18624 | 64 bytes UTF-8 | |
| Sensor 3, S33 dimension | 03 | 18656 | 64 bytes UTF-8 | |
| Sensor 4, S41 dimension | 03 | 18688 | 64 bytes UTF-8 | |
| Sensor 4, S42 dimension | 03 | 18720 | 64 bytes UTF-8 | |
| Sensor 4, S43 dimension | 03 | 18752 | 64 bytes UTF-8 | |
| Sensor 5, S51 dimension | 03 | 18784 | 64 bytes UTF-8 | |
| Sensor 5, S52 dimension | 03 | 18816 | 64 bytes UTF-8 | |
| Sensor 5, S53 dimension | 03 | 18848 | 64 bytes UTF-8 | |
| Sensor 6, S61 dimension | 03 | 18880 | 64 bytes UTF-8 | |
| Sensor 6, S62 dimension | 03 | 18912 | 64 bytes UTF-8 | |
| Sensor 6, S63 dimension | 03 | 18944 | 64 bytes UTF-8 | |
| Sensor 7, S71 dimension | 03 | 18976 | 64 bytes UTF-8 | |
| Sensor 7, S72 dimension | 03 | 19008 | 64 bytes UTF-8 | |
| Sensor 7, S73 dimension | 03 | 19040 | 64 bytes UTF-8 | |
| Sensor 8, S81 dimension | 03 | 19072 | 64 bytes UTF-8 | |
| Sensor 8, S82 dimension | 03 | 19104 | 64 bytes UTF-8 | |
| Sensor 8, S83 dimension | 03 | 19136 | 64 bytes UTF-8 | |

| | | | | |
|-------------------|-------|-------|--------------|--|
| Sensor 1, S11 max | 03,16 | 19200 | 32-bit Float | |
| Sensor 1, S12 max | 03,16 | 19202 | 32-bit Float | |
| Sensor 1, S13 max | 03,16 | 19204 | 32-bit Float | |
| Sensor 2, S21 max | 03,16 | 19206 | 32-bit Float | |
| Sensor 2, S22 max | 03,16 | 19208 | 32-bit Float | |
| Sensor 2, S23 max | 03,16 | 19210 | 32-bit Float | |
| Sensor 3, S31 max | 03,16 | 19212 | 32-bit Float | |
| Sensor 3, S32 max | 03,16 | 19214 | 32-bit Float | |
| Sensor 3, S33 max | 03,16 | 19216 | 32-bit Float | |
| Sensor 4, S41 max | 03,16 | 19218 | 32-bit Float | |
| Sensor 4, S42 max | 03,16 | 19220 | 32-bit Float | |
| Sensor 4, S43 max | 03,16 | 19222 | 32-bit Float | |
| Sensor 5, S51 max | 03,16 | 19224 | 32-bit Float | |
| Sensor 5, S52 max | 03,16 | 19226 | 32-bit Float | |
| Sensor 5, S53 max | 03,16 | 19228 | 32-bit Float | |
| Sensor 6, S61 max | 03,16 | 19230 | 32-bit Float | |
| Sensor 6, S62 max | 03,16 | 19232 | 32-bit Float | |
| Sensor 6, S63 max | 03,16 | 19234 | 32-bit Float | |
| Sensor 7, S71 max | 03,16 | 19236 | 32-bit Float | |
| Sensor 7, S72 max | 03,16 | 19238 | 32-bit Float | |
| Sensor 7, S73 max | 03,16 | 19240 | 32-bit Float | |
| Sensor 8, S81 max | 03,16 | 19242 | 32-bit Float | |
| Sensor 8, S82 max | 03,16 | 19244 | 32-bit Float | |
| Sensor 8, S83 max | 03,16 | 19246 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 min | 03,16 | 19300 | 32-bit Float | |
| Sensor 1, S12 min | 03,16 | 19302 | 32-bit Float | |
| Sensor 1, S13 min | 03,16 | 19304 | 32-bit Float | |
| Sensor 2, S21 min | 03,16 | 19306 | 32-bit Float | |
| Sensor 2, S22 min | 03,16 | 19308 | 32-bit Float | |
| Sensor 2, S23 min | 03,16 | 19310 | 32-bit Float | |
| Sensor 3, S31 min | 03,16 | 19312 | 32-bit Float | |
| Sensor 3, S32 min | 03,16 | 19314 | 32-bit Float | |
| Sensor 3, S33 min | 03,16 | 19316 | 32-bit Float | |
| Sensor 4, S41 min | 03,16 | 19318 | 32-bit Float | |
| Sensor 4, S42 min | 03,16 | 19320 | 32-bit Float | |
| Sensor 4, S43 min | 03,16 | 19322 | 32-bit Float | |
| Sensor 5, S51 min | 03,16 | 19324 | 32-bit Float | |
| Sensor 5, S52 min | 03,16 | 19326 | 32-bit Float | |
| Sensor 5, S53 min | 03,16 | 19328 | 32-bit Float | |
| Sensor 6, S61 min | 03,16 | 19330 | 32-bit Float | |
| Sensor 6, S62 min | 03,16 | 19332 | 32-bit Float | |
| Sensor 6, S63 min | 03,16 | 19334 | 32-bit Float | |
| Sensor 7, S71 min | 03,16 | 19336 | 32-bit Float | |
| Sensor 7, S72 min | 03,16 | 19338 | 32-bit Float | |
| Sensor 7, S73 min | 03,16 | 19340 | 32-bit Float | |
| Sensor 8, S81 min | 03,16 | 19342 | 32-bit Float | |
| Sensor 8, S82 min | 03,16 | 19344 | 32-bit Float | |

| | | | | |
|--------------------------|-------|-------|--------------|--|
| Sensor 8, S83 min | 03,16 | 19346 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 hysteresis | 03,16 | 19400 | 32-bit Float | |
| Sensor 1, S12 hysteresis | 03,16 | 19402 | 32-bit Float | |
| Sensor 1, S13 hysteresis | 03,16 | 19404 | 32-bit Float | |
| Sensor 2, S21 hysteresis | 03,16 | 19406 | 32-bit Float | |
| Sensor 2, S22 hysteresis | 03,16 | 19408 | 32-bit Float | |
| Sensor 2, S23 hysteresis | 03,16 | 19410 | 32-bit Float | |
| Sensor 3, S31 hysteresis | 03,16 | 19412 | 32-bit Float | |
| Sensor 3, S32 hysteresis | 03,16 | 19414 | 32-bit Float | |
| Sensor 3, S33 hysteresis | 03,16 | 19416 | 32-bit Float | |
| Sensor 4, S41 hysteresis | 03,16 | 19418 | 32-bit Float | |
| Sensor 4, S42 hysteresis | 03,16 | 19420 | 32-bit Float | |
| Sensor 4, S43 hysteresis | 03,16 | 19422 | 32-bit Float | |
| Sensor 5, S51 hysteresis | 03,16 | 19424 | 32-bit Float | |
| Sensor 5, S52 hysteresis | 03,16 | 19426 | 32-bit Float | |
| Sensor 5, S53 hysteresis | 03,16 | 19428 | 32-bit Float | |
| Sensor 6, S61 hysteresis | 03,16 | 19430 | 32-bit Float | |
| Sensor 6, S62 hysteresis | 03,16 | 19432 | 32-bit Float | |
| Sensor 6, S63 hysteresis | 03,16 | 19434 | 32-bit Float | |
| Sensor 7, S71 hysteresis | 03,16 | 19436 | 32-bit Float | |
| Sensor 7, S72 hysteresis | 03,16 | 19438 | 32-bit Float | |
| Sensor 7, S73 hysteresis | 03,16 | 19440 | 32-bit Float | |
| Sensor 8, S81 hysteresis | 03,16 | 19442 | 32-bit Float | |
| Sensor 8, S82 hysteresis | 03,16 | 19444 | 32-bit Float | |
| Sensor 8, S83 hysteresis | 03,16 | 19446 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 multiplier | 03,16 | 19500 | 32-bit Float | |
| Sensor 1, S12 multiplier | 03,16 | 19502 | 32-bit Float | |
| Sensor 1, S13 multiplier | 03,16 | 19504 | 32-bit Float | |
| Sensor 2, S21 multiplier | 03,16 | 19506 | 32-bit Float | |
| Sensor 2, S22 multiplier | 03,16 | 19508 | 32-bit Float | |
| Sensor 2, S23 multiplier | 03,16 | 19510 | 32-bit Float | |
| Sensor 3, S31 multiplier | 03,16 | 19512 | 32-bit Float | |
| Sensor 3, S32 multiplier | 03,16 | 19514 | 32-bit Float | |
| Sensor 3, S33 multiplier | 03,16 | 19516 | 32-bit Float | |
| Sensor 4, S41 multiplier | 03,16 | 19518 | 32-bit Float | |
| Sensor 4, S42 multiplier | 03,16 | 19520 | 32-bit Float | |
| Sensor 4, S43 multiplier | 03,16 | 19522 | 32-bit Float | |
| Sensor 5, S51 multiplier | 03,16 | 19524 | 32-bit Float | |
| Sensor 5, S52 multiplier | 03,16 | 19526 | 32-bit Float | |
| Sensor 5, S53 multiplier | 03,16 | 19528 | 32-bit Float | |
| Sensor 6, S61 multiplier | 03,16 | 19530 | 32-bit Float | |
| Sensor 6, S62 multiplier | 03,16 | 19532 | 32-bit Float | |
| Sensor 6, S63 multiplier | 03,16 | 19534 | 32-bit Float | |
| Sensor 7, S71 multiplier | 03,16 | 19536 | 32-bit Float | |
| Sensor 7, S72 multiplier | 03,16 | 19538 | 32-bit Float | |
| Sensor 7, S73 multiplier | 03,16 | 19540 | 32-bit Float | |

| | | | | |
|--------------------------|-------|-------|----------------|---------------------------|
| Sensor 8, S81 multiplier | 03,16 | 19542 | 32-bit Float | |
| Sensor 8, S82 multiplier | 03,16 | 19544 | 32-bit Float | |
| Sensor 8, S83 multiplier | 03,16 | 19546 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 offset | 03,16 | 19600 | 32-bit Float | |
| Sensor 1, S12 offset | 03,16 | 19602 | 32-bit Float | |
| Sensor 1, S13 offset | 03,16 | 19604 | 32-bit Float | |
| Sensor 2, S21 offset | 03,16 | 19606 | 32-bit Float | |
| Sensor 2, S22 offset | 03,16 | 19608 | 32-bit Float | |
| Sensor 2, S23 offset | 03,16 | 19610 | 32-bit Float | |
| Sensor 3, S31 offset | 03,16 | 19612 | 32-bit Float | |
| Sensor 3, S32 offset | 03,16 | 19614 | 32-bit Float | |
| Sensor 3, S33 offset | 03,16 | 19616 | 32-bit Float | |
| Sensor 4, S41 offset | 03,16 | 19618 | 32-bit Float | |
| Sensor 4, S42 offset | 03,16 | 19620 | 32-bit Float | |
| Sensor 4, S43 offset | 03,16 | 19622 | 32-bit Float | |
| Sensor 5, S51 offset | 03,16 | 19624 | 32-bit Float | |
| Sensor 5, S52 offset | 03,16 | 19626 | 32-bit Float | |
| Sensor 5, S53 offset | 03,16 | 19628 | 32-bit Float | |
| Sensor 6, S61 offset | 03,16 | 19630 | 32-bit Float | |
| Sensor 6, S62 offset | 03,16 | 19632 | 32-bit Float | |
| Sensor 6, S63 offset | 03,16 | 19634 | 32-bit Float | |
| Sensor 7, S71 offset | 03,16 | 19636 | 32-bit Float | |
| Sensor 7, S72 offset | 03,16 | 19638 | 32-bit Float | |
| Sensor 7, S73 offset | 03,16 | 19640 | 32-bit Float | |
| Sensor 8, S81 offset | 03,16 | 19642 | 32-bit Float | |
| Sensor 8, S82 offset | 03,16 | 19644 | 32-bit Float | |
| Sensor 8, S83 offset | 03,16 | 19646 | 32-bit Float | |
| | | | | |
| Sensor 1 ID | 03 | 19700 | 16 bytes UTF-8 | Example: 2860B85F07000094 |
| Sensor 2 ID | 03 | 19708 | 16 bytes UTF-8 | |
| Sensor 3 ID | 03 | 19716 | 16 bytes UTF-8 | |
| Sensor 4 ID | 03 | 19724 | 16 bytes UTF-8 | |
| Sensor 5 ID | 03 | 19732 | 16 bytes UTF-8 | |
| Sensor 6 ID | 03 | 19740 | 16 bytes UTF-8 | |
| Sensor 7 ID | 03 | 19748 | 16 bytes UTF-8 | |
| Sensor 8 ID | 03 | 19756 | 16 bytes UTF-8 | |
| | | | | |
| Sensor 1, S11 value | 03 | 19800 | 32-bit Float | |
| Sensor 1, S12 value | 03 | 19802 | 32-bit Float | |
| Sensor 1, S13 value | 03 | 19804 | 32-bit Float | |
| Sensor 2, S21 value | 03 | 19806 | 32-bit Float | |
| Sensor 2, S22 value | 03 | 19808 | 32-bit Float | |
| Sensor 2, S23 value | 03 | 19810 | 32-bit Float | |
| Sensor 3, S31 value | 03 | 19812 | 32-bit Float | |
| Sensor 3, S32 value | 03 | 19814 | 32-bit Float | |
| Sensor 3, S33 value | 03 | 19816 | 32-bit Float | |
| Sensor 4, S41 value | 03 | 19818 | 32-bit Float | |

| | | | | |
|----------------------------|----|-------|-------------------|-----------------------|
| Sensor 4, S42 value | 03 | 19820 | 32-bit Float | |
| Sensor 4, S43 value | 03 | 19822 | 32-bit Float | |
| Sensor 5, S51 value | 03 | 19824 | 32-bit Float | |
| Sensor 5, S52 value | 03 | 19826 | 32-bit Float | |
| Sensor 5, S53 value | 03 | 19828 | 32-bit Float | |
| Sensor 6, S61 value | 03 | 19830 | 32-bit Float | |
| Sensor 6, S62 value | 03 | 19832 | 32-bit Float | |
| Sensor 6, S63 value | 03 | 19834 | 32-bit Float | |
| Sensor 7, S71 value | 03 | 19836 | 32-bit Float | |
| Sensor 7, S72 value | 03 | 19838 | 32-bit Float | |
| Sensor 7, S73 value | 03 | 19840 | 32-bit Float | |
| Sensor 8, S81 value | 03 | 19842 | 32-bit Float | |
| Sensor 8, S82 value | 03 | 19844 | 32-bit Float | |
| Sensor 8, S83 value | 03 | 19846 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 row value | 03 | 19900 | 32-bit Float | |
| Sensor 1, S12 row value | 03 | 19902 | 32-bit Float | |
| Sensor 1, S13 row value | 03 | 19904 | 32-bit Float | |
| Sensor 2, S21 row value | 03 | 19906 | 32-bit Float | |
| Sensor 2, S22 row value | 03 | 19908 | 32-bit Float | |
| Sensor 2, S23 row value | 03 | 19910 | 32-bit Float | |
| Sensor 3, S31 row value | 03 | 19912 | 32-bit Float | |
| Sensor 3, S32 row value | 03 | 19914 | 32-bit Float | |
| Sensor 3, S33 row value | 03 | 19916 | 32-bit Float | |
| Sensor 4, S41 row value | 03 | 19918 | 32-bit Float | |
| Sensor 4, S42 row value | 03 | 19920 | 32-bit Float | |
| Sensor 4, S43 row value | 03 | 19922 | 32-bit Float | |
| Sensor 5, S51 row value | 03 | 19924 | 32-bit Float | |
| Sensor 5, S52 row value | 03 | 19926 | 32-bit Float | |
| Sensor 5, S53 row value | 03 | 19928 | 32-bit Float | |
| Sensor 6, S61 row value | 03 | 19930 | 32-bit Float | |
| Sensor 6, S62 row value | 03 | 19932 | 32-bit Float | |
| Sensor 6, S63 row value | 03 | 19934 | 32-bit Float | |
| Sensor 7, S71 row value | 03 | 19936 | 32-bit Float | |
| Sensor 7, S72 row value | 03 | 19938 | 32-bit Float | |
| Sensor 7, S73 row value | 03 | 19940 | 32-bit Float | |
| Sensor 8, S81 row value | 03 | 19942 | 32-bit Float | |
| Sensor 8, S82 row value | 03 | 19944 | 32-bit Float | |
| Sensor 8, S83 row value | 03 | 19946 | 32-bit Float | |
| | | | | |
| Sensor 1, S11 alarm status | 03 | 20000 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 1, S12 alarm status | 03 | 20001 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 1, S13 alarm status | 03 | 20002 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 2, S21 alarm status | 03 | 20003 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 2, S22 alarm status | 03 | 20004 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 2, S23 alarm status | 03 | 20005 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 3, S31 alarm status | 03 | 20006 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 3, S32 alarm status | 03 | 20007 | 16-bit unsign int | normal (0), alarm (1) |

| | | | | |
|----------------------------|-------|-------|-------------------|-------------------------------|
| Sensor 3, S33 alarm status | 03 | 20008 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 4, S41 alarm status | 03 | 20009 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 4, S42 alarm status | 03 | 20010 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 4, S43 alarm status | 03 | 20011 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 5, S51 alarm status | 03 | 20012 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 5, S52 alarm status | 03 | 20013 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 5, S53 alarm status | 03 | 20014 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 6, S61 alarm status | 03 | 20015 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 6, S62 alarm status | 03 | 20016 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 6, S63 alarm status | 03 | 20017 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 7, S71 alarm status | 03 | 20018 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 7, S72 alarm status | 03 | 20019 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 7, S73 alarm status | 03 | 20020 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 8, S81 alarm status | 03 | 20021 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 8, S82 alarm status | 03 | 20022 | 16-bit unsign int | normal (0), alarm (1) |
| Sensor 8, S83 alarm status | 03 | 20023 | 16-bit unsign int | normal (0), alarm (1) |
| | | | | |
| Save configuration | 03,06 | 50000 | 16-bit unsign int | unsaved (0), saved (1) |
| Restart device | 03,06 | 50001 | 16-bit unsign int | cancel (0), restart (1) |
| Temperature unit | 03,06 | 50002 | 16-bit unsign int | Celsius (0), Fahrenheit (1) |
| HW error | 03,06 | 50003 | 16-bit unsign int | noErr (0), hwErr (1) |
| Device ID | 03 | 50100 | 18 bytes UTF-8 | Example: 5c:32:c5:00:ac:52 |
| Hostname | 03 | 50200 | 16 bytes UTF-8 | |
| Device IP | 03 | 50300 | 16 bytes UTF-8 | Example: 192.168.1.2 |

8.4. MODBUS RTU

8.4.1. Communication parameters

For MODBUS RTU, TCW210-TH supports the following communication parameters:

- Baud rate – 2400, 4800, 9600, 19200, 38400, or 57600;
- Data bits – 8;
- Stop bits – 1 or 2;
- Parity – Odd or Even;

As factory default communication parameters the device uses standard ones for MODBUS RTU:

- Baud rate – 19200;
- Data bits – 8;
- Stop bits – 1;
- Parity – Even;


8.4.2. Teracom sensors update tool

TCW210-TH supports Teracom sensor FW update tool.

The tool is available at <http://device.ip.address/teracom485.htm>.

Attention! To make any changes to MODBUS RTU sensor it should be alone on the RS-485 bus.

8.4.2.1. Sensor settings



The screenshot shows a web interface titled "Sensor settings". It contains two rows of information: "Sensor info" with the value "TSH3xx-v3.02" and "Status" with the message "You can proceed with the update of sensor.". Below this information is a button labeled "Scan MB".

The tool works with the current MODBUS RTU communication parameters.

To avoid collisions the good practice is to set TCW210-TH and the sensor with the factory default MODBUS RTU communication parameters. This will ensure smooth operation. The default MODBUS RTU communication parameters for TCW210-TH are described in 8.4.1. Communication parameters.

Before to make any changes it is strongly recommended to scan for sensor settings. This will inform about the current FW version of the sensor but also will check if the sensor is alone on the bus.

8.4.2.2. Sensor FW update



The screenshot shows a web interface titled "Sensor FW update". It features a file selection area with a "Choose File" button and the text "No file chosen". Below this is an "Upload" button. Further down, it displays "Loaded Firmware" as "TSH3xxV3-v1.00" and "Status" as "Idle". At the bottom, there is an "Update sensor" button.

To arrange the FW update, the appropriate file should be uploaded to the sensor first and after this, the button "Update" should be pressed.

8.5. Logger

The logger utilizes circular buffer in FLASH memory. When it is full, the new data overwrites the oldest one. In this manner FLASH memory stores full log all the time. There isn't a command to clear the log. Copy of full log is always available for download.

The number of records depends on how long descriptions and what kind of characters are used. In the worst case (15 bytes description with characters from the highest part of UTF-8) the number of records is about 52000. This number is enough for 36 days with records every 1 minute.

The new data can be periodically uploaded as a file to the dedicated HTTP server in time intervals – 1, 2, 3, 4, 6, 8, 12 and 24 hours. The data is sent in CSV format. The semicolon is used for a delimiter.

The first row of the log file is always header. All rows, including the header, start with record ID and time stamp.

Structure of one row (record) of the log is as follows:

| ID | Time | Type of record | Inputs value | Relays | Alarm conditions |
|----|------|----------------|--------------|--------|------------------|
|----|------|----------------|--------------|--------|------------------|

| | |
|------------------|--|
| ID | 32-bit unique number for every row (record). |
| Time | time stamp of record, in format yyyy.mm.dd, hh:mm:ss. |
| Type of record | following types of records are available: "Time" for periodical record; "Event" for record initiate by alarm condition; "Type" for header record; "Start" after power-up condition; "Restart" after reset condition; "Power Down" after power-down condition; "Bad" for problematic record. |
| Inputs value | sensors. |
| Alarm conditions | show condition for every input, "1" means an active alarm. |

Example of log file:

```
1131901;15.10.2015,01:02:23;Type;S11/°C;S12;S21/°C;S22;S31/°C;S32;S41/°C;S42;S51/°C;S52;S61/°C;S62;S71/°C;S72;S81/°C;S82;A1/V;A2/V;D1;D2;R1;R2;S11/°C;S12;S21/°C;S22;S31/°C;S32;S41/°C;S42;S51/°C;S52;S61/°C;S62;S71/°C;S72;S81/°C;S82;A1/V;A2/V;D1;D2;
1131902;15.10.2015,01:02:23;Time;18.250;;18.375;;18.125;;18.500;;18.188;;18.125;;18.375;;18.375;;11.352;0.065;1;0;1;0;1;;1;;1;;1;;1;;1;1;0;1;0;
1131903;15.10.2015,01:02:23;Event;18.250;;18.438;;18.125;;18.500;;18.188;;18.125;;18.313;;18.375;;11.352;0.066;0;1;0;1;1;;1;;1;;1;;1;;1;1;0;0;1;
1131904;15.10.2015,01:02:24;Time;18.250;;18.438;;18.125;;18.500;;18.188;;18.125;;18.313;;18.375;;11.352;0.066;0;1;0;1;1;;1;;1;;1;;1;;1;1;0;0;1;
1131905;15.10.2015,01:02:25;Time;18.250;;18.375;;18.125;;18.500;;18.188;;18.125;;18.313;;18.375;;11.352;0.066;0;1;0;1;1;;1;;1;;1;;1;;1;1;0;0;1;
1131906;15.10.2015,01:02:26;Time;18.250;;18.375;;18.125;;18.500;;18.188;;18.125;;18.313;;18.313;;11.352;0.066;0;1;0;1;1;;1;;1;;1;;1;;1;1;0;0;1;
1131907;15.10.2015,01:02:27;Time;18.250;;18.375;;18.125;;18.438;;18.188;;18.125;;18.313;;18.313;;11.352;0.066;0;1;0;1;1;;1;;1;;1;;1;;1;1;0;0;1;
1131908;15.10.2015,01:02:27;Event;18.250;;18.375;;18.125;;18.438;;18.188;;18.125;;18.313;;18.313;;2.198;9.092;0;1;0;1;1;;1;;1;;1;;1;;1;0;0;0;1;
```

9. Factory default settings

TCW210-TH can be restored to its original factory default settings in 3 different ways.

9.1. Factory default from WEB interface

If the button “Factory default” from Administration->Backup/Restore is pressed, all parameters return to factory default except Network settings.

9.2. Factory default with the reset button

If the reset button is pressed for more than 5 seconds, while the device is working, all Network settings go to factory default.

9.3. General factory default with the reset button

For factory default reset of all parameters following steps should be executed:

- Press and hold the RESET button, then turn on the power supply;
- Yellow LED shines and red LED blinks about 5 times on a second;
- After about 5 seconds red LED will turn off, the button can be released;
- Yellow LED flashes on 1 second and red LED shines – the device is in working mode, with factory default settings.



The factory default settings are:

| | |
|-------------------|---------------|
| Username | admin |
| Password | admin |
| IP Address | 192.168.1.2 |
| Subnet Mask | 255.255.255.0 |
| Default Gateway | 192.168.1.1 |
| SNMPConfiguration | disabled |
| readCommunity | public |
| writeCommunity | private |

10. Environment information

This equipment is intended for use in a Pollution Degree 2 environment, at altitudes up to 2000 meters. When the controller is a part of a system, the other elements of the system shall comply with the EMC requirements and shall be intended for use in the same ambient conditions.

11. Safety

This device must not be used for medical, life-saving purposes or for any purpose where its failure could cause serious injury or the loss of life.

To reduce the risk of fire, only flexible stranded wire, with cross section 0.5mm² or larger for wiring of digital and analog inputs and relay output of the device should be used.

To avoid electric shock and fire hazard, do not expose this product to liquids, rain, or moisture. Objects filled with liquids, such as vases, should not be placed on this device.

There is a risk of overheating (damage) of the controller, if recommended free spaces to adjacent devices are not ensured. The joint part with external component shall have space for attachment/removal of the cable after installation.

Teracom does not guarantee successful operation of the product if the product was used under conditions deviating from the product specifications.

To ensure that the device works correctly follow the steps below:

- ensure that the device is installed correctly, refer to this user manual;
- log in to the devices via a browser program;
- make proper setup;
- install sensor TSH1XX or TST1XX on the 1-Wire bus;
- install sensor TSH3XX or TST3XX on the RS-485 bus;
- go to “Monitoring page” of WEB interface – proper parameters value should be displayed at the same time flashing “STS” led should indicate the proper operation.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Teracom Ltd. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

12. Maintenance

Upon completion of any service or repairs to the device or once per year, a safety check must be performed to determine that this product is in proper operating condition.

Clean the device only with dry cloth. Do not use a liquid cleaner or an aerosol cleaner. Do not use a magnetic/static cleaning device (dust remover) or any kind of abrasive materials to clean the device.




Fig.1